



**INSTRUCTION MANUAL  
PARTS LIST**

**MINI-10**

## INTRODUCTION

We thank you for having selected our MINI-10 Diesel engine for your use.

BEFORE SETTING THE ENGINE RUNNING, it is important to read the operation and maintenance instructions contained in this booklet closely to follow them strictly.

If you have any doubt or query on your engine or in case of breakdown, please contact the nearest dealer where you will receive due attention.

### ATTENTION

So that spare parts deliveries may be exact and immediate, it is extremely important to give the details listed below in your order:

- a) Type of engine (given on the nameplate).
- b) Engine number (given on the top of the block, alternator side).
- c) Number and description of the required part.

**OBSERVATIONS:** The descriptions and illustrations given in this instruction booklet are not binding. Therefore, whilst maintaining the main features of the engine described and illustrated here, SOLE, S.A. reserves all rights to make modifications in parts, details and accessories as may be required for any technical or commercial reasons.

## CONTENTS

|   |   |  |    |
|---|---|--|----|
| 1 | - | Precautions when using the engine . . . . .                | 5  |
| 2 | - | Specifications . . . . .                                   | 6  |
| 3 | - | Use . . . . .  | 7  |
|   |   | 3.1 - Before starting up . . . . .                         | 7  |
|   |   | 3.2 - Preparations for starting up . . . . .               | 7  |
|   |   | 3.3 - Starting up . . . . .                                | 9  |
|   |   | 3.4 - With engine running . . . . .                        | 10 |
|   |   | 3.5 - Stoppage . . . . .                                   | 11 |
| 4 | - | Maintainance . . . . .                                     | 12 |
|   |   | 4.1 - Lubrication system . . . . .                         | 12 |
|   |   | 4.2 - Fuel system . . . . .                                | 15 |
|   |   | 4.3 - Inlet system . . . . .                               | 19 |
|   |   | 4.4 - Cooling system . . . . .                             | 20 |
|   |   | 4.5 - Electrical system . . . . .                          | 22 |
|   |   | 4.6 - Reversing reduction gear . . . . .                   | 23 |
| 5 | - | Periodical inspections . . . . .                           | 29 |
|   |   | 5.1 - Daily check prior to using the engine . . . . .      | 29 |
|   |   | 5.2 - Maintainance after the first 50 hours . . . . .      | 29 |
|   |   | 5.3 - Maintainance after every 100 hours running . . . . . | 31 |
|   |   | 5.4 - Maintainance after every 200 hours running . . . . . | 31 |
|   |   | 5.5 - Maintainance after every 400 hours running . . . . . | 32 |
|   |   | 5.6 - Maintainance after every 800 hours running . . . . . | 32 |
| 6 | - | Troubleshooting . . . . .                                  | 34 |
| 7 | - | Service details . . . . .                                  | 37 |
| 8 | - | Spare parts description list . . . . .                     | 38 |

## 1 - PRECAUTION WHEN USING THE ENGINE

- \* Always use an appropriate oil and check the oil pressure while the engine is running.
- \* Use clean fuel, free from impurities and water.
- \* Prevent water and air from entering into the fuel circuit.
- \* If the starter motor pinion does not mesh with the crown gear on starting up, turn the key again after the motor has stopped running.
- \* Pay attention to the colour of the exhaust gases.
- \* Clean or periodically change the fuel and oil filters.
- \* Change the oil as specified.
- \* Check that the cooling water circulates correctly through the engine.

### **Safety precautions**

- \* Do not touch any moving parts of the engine while this is running.
- \* Do not touch hot parts, such as the exhaust pipe, and keep any inflammable materials away from them.
- \* Inspect and adjust engine parts only when stopped.
- \* Check engine oil and fuel levels and refill only when the engine is stopped.
- \* Use always tools of an appropriate size and work with care when effecting any service operation.

## 2 - SPECIFICATIONS

|                             |   |
|-----------------------------|---|
| Type:                       | Vertical water cooled 4 stroke  |
| N.º of cylinders:           | Two.  |
| Bore:                       | 65 mm. (2,55")  |
| Stroke:                     | 68 mm. (2,68")  |
| Capacity:                   | 451 c. c. (27,52")  |
| Compression ratio:          | 23:1  |
| Power (DIN6270-B):          | 9 Hp (6,62 KW)  |
| Maximum r. p. m.            | 3.000   |
| Gear box:                   | Mechanical RONIM III type Ratio 1,9:1   |
| Maximum installation angle: | 20°   |
| Lubrication :               | Forced, by rotary pump.   |
| Oil capacity:               | Engine 1,8 l.<br>Gear box, 0,4 l.   |
| Type of oil:                | HD<br>20° or above SAE-30)<br>5° to 20° SAE-20) - SAE-10W-30<br>5° or below SAE-10)   |
| Cooling:                    | Fresh water, whit heat exchanger  |
| Cooling water capacity:     | litres  |
| Injection system:           | Bosch M. type.<br>Centrifugal regulator   |
|                             | Injector pressure $160 \begin{matrix} + 10 \\ 0 \end{matrix}$   |
| Electrical system:          | See wiring diagrams, pages 25, 26 and 27<br>Starter 12 V. 0,9 KW.<br>Alternator 12 V. 35 A.<br>Glow plugs, sheated type.<br>10 A. Fuse. |

## 3 - USE

### 3.1 - BEFORE STARTING UP

Your new engine requires a 50 HOUR running-in period for setting all moving parts and obtaining a high performance.


Carry out this running-in carefully, bearing in mind the following points:

#### WARNING

- \* Run the motor at slow-running speed and warm up for at least 5 minutes.
- \* Avoid hasty acceleration.

### 3.2 - PREPARATIONS FOR STARTING UP

#### 1) Filling of engine and reverse gear with oil



Fill the engine with the recommended oil up to the upper mark on the dipstick (Fig. 1) through the oil filler hole. Fill the the reverse gear with oil up to the level mark on the dipstick through the hole (Fig. 2).

Use the same type of oil as for the engine.

Fig. 1




Fig. 2

**2) Filling of fuel tank**

Fill the fuel tank with clean, filtered gasoil.

Check that the tank is quite clean and free from iron or polyester particles. Open the fuel valve.

**3) Filling water system**

Fill the system with clean water up to the filler opening. In winter, add antifreeze (Fig. 3)

**4) Open the water inlet valve**

**5) Purging of fuel circuit**


First purge the fuel filter and then the injection pump.

(For further details check «Fuel circuit purge» in Chapter (4.2).

**6) Connection of battery disconnecter**

Connect the battery disconnecter.

Fig. 3




### 3.3 - STARTING UP

#### 1) Reverse gear neutral position

Set the clutch to neutral and open the throttle half way.

#### 2) Setting of ignition key in position «1»



Set the ignition key in position «1» and check that the pilot lights are illuminated and the alarm sounds (Fig. 4)

Fig. 4

#### 3) Pre-heating of glow plugs.

Turn the ignition key to position «P» (warming-up) until the glow plug indicator becomes sufficiently red hot.

The normal warm-up time is 20 seconds. In cold weather, follow the table as below:

| Temperature    | Warm-up time       |
|----------------|--------------------|
| + 5° or above  | Approx. 20 seconds |
| + 5°C to -5°C  | Approx. 30 seconds |
| - 5°C or below | Approx. 60 seconds |

Notwithstanding, the warm-up period should not last more than 2 minutes to avoid shortening the plug life.

If the plug indicator does not become red hot, it should be checked by a SOLE Service Centre.



#### 4) Starting up

Turn the ignition key to position «START» and hold it there until the engine fires. If the engine does not fire, although the key is held in position «START» for 10 seconds, release the key for 30 seconds and thereafter try to start the engine up again, after allowing for a sufficient warm-up of the plug. The starter motor must never be operated for more than 30 seconds at a time.

Once the engine has fired, turn the key to position ON and leave it there while running.

After starting, check that the oil pressure and battery charge pilot lights are extinguished.

#### 5) Warm-up

Warm up the engine for about 5 minutes, allowing it to run light at half throttle.

#### IMPORTANT:

While the engine is running, do not turn the key to position «START», since in this case the starter motor would be damaged.

If the engine is warm, the warm-up operations are not required in this case, turn the key to position «START» and hold it there until the engine fires. Once the engine has fired, return the key to position ON.

#### 3.4 - WITH ENGINE RUNNING

- \* Check that the cooling water is flowing.
- \* Check that there are no water or oil leaks.
- \* Check that the oil pressure pilot light is extinguished.
- \* Check that the exhaust fumes are as follows:

- While the engine is cold: White smoke
- As the engine warms up: Almost smokeless
- When the engine is overloaded: A slight amount of black smoke

**IMPORTANT:**

Always change gear with the engine at slow running speed.

### 3.5. - STOPPAGE

- 1) Set the engine to slow running and the clutch to neutral.
- 2) Push the Stop button until the engine has completely stopped.
- 3) With the engine stopped, set the ignition key to position OF. The battery will be discharged if the key is left in position ON.

To prevent this, remove the key after stopping the engine.

If the engine is not going to be used for a long period of time, it is advisable to close the water and fuel valves and to disconnect the battery.

**IMPORTANT:**

The Stop button does not operate if the key is not in position ON.

## 4.4 - MAINTAINANCE

### 4.1 - LUBRICATION SYSTEM

#### 1 - Correct viscosity of oil

Use an oil having a viscosity appropriate to the local ambient temperature. The use of an all-season SAE-10W-30 multigrade oil is recommended since this affords a minimum viscosity variation at different temperatures (see Specifications Section).

#### 2 - Oil pressure

To help you monitor the oil pressure while the engine is running there is an oil pressure warning light and an alarm horn.

- During normal running:

The oil pressure is normal if the light is extinguished.

- When starting:

The light should be illuminated and the horn sounding.

The light will become illuminated during normal running if the oil pressure drops below 0.2-0.4 kg/cm<sup>2</sup> and in such case you should consult your nearest SOLE Service Centre.

#### NOTE:

If the oil pressure drops or the cooling water excessively overheats, the alarm

### 3 - Oil change

#### a) Engine

Change the engine oil after the first 50 hours running and thereafter at intervals of 100 hours.

To change the oil, drain the old oil with the aid of the drain pump through the dipstick hole (Fig. 5).




Fig. 5

After the old oil has been removed, pour in new oil through the filler opening in the rocker arm cover (Fig. 7). Next idle the engine for several minutes.


Then stop it and check the oil level by taking out the dipstick, cleaning it with a rag, putting it back and pressing it home. Now take it out again to check the level.



Fig. 5 bis

#### NOTE:

Remember that the dipstick gives a correct level when the engine is horizontal, therefore the degree of engine rake should be taken into account when checking the level.



b) Reverse gear  
 The reverse gear has its own lubrication independent from that of the engine.  
 To change the oil, drain the old oil with the aid of the drain pump through the dipstick hole or removing the plug underneath the reverse gear. (Fig. 6).

Fig. 6

#### 4 - Oil filter change

Change the oil filter after the first 50 hours running and thereafter at intervals of 100 hours.  
 The oil filter is an easy-to-handle cartridge type not requiring internal cleaning.

On fitting the new oil filter, rub a little engine oil on the seal and screw up hand-tight.  
 After replacing the filter, set the engine running and check for leaks (Fig. 7).




Fig. 7

## 4.2 - FUEL SYSTEM

### 1 - Gasoil


Always use clean, filtered gasoil. Never use kerosene or heavy oils.

Fill with fuel beforehand. In cold weather, a lot of water vapour is produced when there is a lot of air in the fuel tank. Therefore the tank should be kept as full as possible.

When filling the tank, try to avoid impurities and water, always using clean plastic containers and filter the fuel whenever possible.

Also make sure that the tank is free from water and dirt.

### 2 - Fuel system purge



The presence of air in the fuel system will prevent the engine from starting up. Therefore it is absolutely necessary to inspect and pay due attention to the fuel system to check for air leaks.

To purge the air from the fuel system, first loosen the fuel filter ventilation screw (1) and re-tighten the screw after bubbling ceases. Thereafter purge the air by loosening the fuel filter and injection pump ventilation screws (2) and (3), in this order, and then re-tighten the screws (Fig. 8).

Thereafter turn the engine over for a few seconds with the starter motor, with the lever in the «fully open» position so that the air may be removed from the piston, the fuel injection tubes and the nozzles.

This operation may also be effected by operating the supply pump lever located at the top of the reverse gear (Fig. 9) until the air is purged.





Fig. 9

The engine may be started up by following the above listed sequence of operations. If the engine does not start up easily, remove the injection screws from the nozzle side, setting the fuel lever in the «fully open» position, operate the starter motor or the fuel pump lever and then firmly tighten up the nuts.

### **3 - , Cleaning and replacement of fuel filter**

The fuel filter is of the easy-to-handle cartridge type. The accumulation of dirt and water in the filter causes operating difficulties. Remove the engine filter every 100 running hours, clean the outside and remove the two ventilation screws. Purge any water that has collected inside and thereafter rinse the filter in clean gasoil (Fig. 10).



The filter should be replaced after every 200 hours running. If a fuel decanter filter is fitted apart from the engine, drain it every 100 hours and replace the cartridge every 200 hours.

Fig. 10

#### 4 - Fuel injection pump

The fuel injection pump is one of the most important parts of a Diesel engine and, therefore, great care is required when handling it. Moreover, the injection pump has been very carefully adjusted at the works and should never be handled carelessly. When any adjustment is required, it should be effected by an authorized SOLE Service Centre, since a precision pump tester and specialized knowledge are needed.

The requirements for handling fuel injection pumps are as follows:

- Always use fuels free from impurities.
- Clean and replace the fuel filters periodically.

#### 5 - Setting of slow running speed

Slacken off the locknut of the screw in front of the gas lever and tighten up or slacken off the nut according to whether it is wanted to increase or reduce the slow running speed (Fig. 11). Then re-tighten the locknut.






Fig. 11

**IMPORTANT:**

Never touch the sealed screw located behind the gas lever.




Fig. 12


**6 . Fitting of remote control to engine**

The engine fuel system comprises a single lever for accelerating and stopping the engine. Therefore, the gas lever slotted head has to be fitted as shown in Fig. 12.

### 4.3 - INLET SYSTEM

#### 1 - Replacement of inlet air filter element

Change the air filter element every 400 hours.



To replace the filter, slacken off the filter centre nut, remove the cover and pull out the filter element. Insert a new element (Fig. 12 bis).

The element **MAY NOT** be cleaned.

Fig. 12 (bis)


Fig. 13

It is important to install a filter between the engine and the bottom cock to prevent the impurities contained in the sea water from obstructing the cooling pipes and seizing the thermostat.

Clean the filter every 50 hours by slackening off the wing nut and removing the filter element. Clean out

and replace, making sure that the cover is properly seated on the O-ring. (Fig. 13).

Then set the engine running to check for water leaks from the cover.



## 4.4 - COOLING SYSTEM

### 1 - Fresh water system

The engine is cooled by fresh water, contaminated as little as possible, such as tap water or rainwater. Using hard or dirty water will cause formation of scale inside the system, which will considerably reduce the cooling effect.

If low temperatures, i.e. below 0°C, are a hazard, antifreeze must be added to the cooling water.

The proportion of antifreeze depends on the anticipated temperatures. The antifreeze makers give guidance for this on the package labels of their products. In any case, the following table shows the proportions appropriate for the expected temperatures.

| Concentration of antifreeze (%) | 13         | 23          | 30         | 35          | 45           | 50           | 60           |
|---------------------------------|------------|-------------|------------|-------------|--------------|--------------|--------------|
| Temperature in °C<br>in °F      | -5<br>(23) | -10<br>(14) | -15<br>(5) | -20<br>(-4) | -30<br>(-22) | -40<br>(-40) | -50<br>(-58) |


Be sure to clean the cooling system before adding antifreeze.

#### NOTE

It is advisable to choose an antifreeze concentration corresponding to a temperature about 5°C lower than the actual atmospheric temperature.

Cooling system capacity: 3'25 litres.

Fig. 14



## 2 - Sea water system

### a) Water pump

The water pump is located on the right hand side of the engine at the front, underneath the alternator. The rotor is made of neoprene and must not be allowed to run dry. If it without water it can break. It is therefore important always to carry a spare.

To replace the rotor, turn off the water inlet cock, take off the pump cover and remove the rotor from its shaft, using two screwdrivers for leverage. Clean the seat and fit a new rotor. Replace the cover with a new gasket (Fig. 14).

Open the bottom cock.




Fig. 15




Fig. 15 (bis)

## 3 - Drainage

The engine two drain cocks, for fresh water (Figs. 15 and 15 bis).

## 4.5 - ELECTRICAL SYSTEM

1 - The engine is equipped with a 12 V system and the electrical circuit is shown in the following diagrams (Figs. 20 and 21).

To install electrical equipment, connect it correctly, following the diagram and, at the same time, check for any damaged cable sheathing and whether the earth connection is correct.

### 2 - Alternator belt tension

The alternator belt is properly tensioned if it moves from 10 to 12 mm when pressed with your finger.

Too much tension may cause rapid wearing of the and the alternator bearings.

On the other hand, if it is too slack or is oily, there may be an insufficient charge due to slipping of the belt.

Never try to adjust the belt tension with engine running.

To tension the alternator belt, loosen the two alternator holding bolts, one located underneath and the other on the tension device, tension up the belt by levering with the alternator until the appropriate tension is obtained. Then retighten the two bolts. (Fig. 16).




Fig. 16

### 3 - Fuse

The electrical system is protected by a 40 A fuse, fitted alongside the starter motor on the lead running from the latter to the control panel (see diagram on page 25).

If no power reached the panel, make sure that the fuse is not burnt out. If it is, install a new one.



## 4.6 · REVERSING REDUCTION GEAR

The ronim mechanically operated reversing gear is made from aluminium alloy having high mechanical strength and resistance to sea water.

### 1) Operation

With the engine running at tick-over speed, gently push the reverse gear lever forwards (ahead) or backwards (astern) as desired.

### 2) Remote control connection

Connect the control cable to the lever with the ball joint provided and attach the cable with the clamp.

Once the control is mounted, adjust it so that it moves the same distance forwards as backwards and do not open the accelerator until the gear has properly entered. (Fig. 17) To check that the assembly is correct, proceed as follows:

Push the reverse gear lever and the remote control lever to 'ahead'.

At this stage, line up the bores of the ball joint (A) and lever (B) (Fig. 18).

Any adjustment is made with the reverse gear lever bores and with the elongate holes of the cable attachment support.





Fig. 17

Fig. 18



(B)

(A)

### 3) Adjustment of control

Slacken off the control attachment screws and move it sideways to the right or the left until the same stroke is obtained both 'ahead' and 'astern'. Then retighten the screws (Fig. 19)




Fig. 19







Fig. 20








| Nº | CABLE FUNCTION | COLOUR    |
|----|----------------|-----------|
| 1  | NEGATIF        | BLACK     |
| 2  | WATER ALARM    | WHITE     |
| 3  | BATTERY CHARGE | WHITE/RED |
| 4  | TACHOMETER     | VIOLET    |
| 6  | OIL ALARM      | BLUE      |
| 7  | ENGINE STOP    | RED       |

|    |                |       |
|----|----------------|-------|
| 8  | GLOW PLUES     | GREEN |
| 9  | STARTER        | PINK  |
| 10 | COURRONT TAP + | RED   |



| PUNTO | DESCRIPTION      |
|-------|------------------|
| H     | CHARGE LAMP      |
| G     | OIL PRESS. LAMP  |
| F     | WATER TEMP. LAMP |
| E     | STARTER SWITCH   |
| D     | ALARM HORN       |
| C     | TACHOMETER       |
| B     | GLOW LAMP        |
| A     | STOP SWITCH      |

Fig. 21

○ Inspection, adjustment of filling   □ Cleaning   ● Change   △ Drain

| Item to inspect  | Intervals |                |                 |                 |                 |                 |     | Long term |
|--|-----------|----------------|-----------------|-----------------|-----------------|-----------------|-----|-----------|
|  | Daily     | First 50 hours | Every 100 hours | Every 200 hours | Every 400 hours | Every 800 hours |     |           |
| Engine body<br>Tighten setscrews<br>Valve clearance<br>Engine slow running speed<br>Engine compression ratio                                   |           | ○ ○ ○ ○ ○      | ○               |                 | ○ ○             | ○               |     |           |
| Lubrication system<br>Engine oil<br>Reverse gear oil<br>Oil filter   | ○ ○       | ● ● ●          | ● ● ●           |                 |                 |                 |     |           |
| Fuel system<br>Fuel<br>Fuel tank<br>Fuel filter<br>Fuel Filter with water trap (if any)<br>Nozzle<br>Injection pump                            | ○         | ○              | □ △             | ● ○             |                 | ○               | △ □ |           |
| Air filter   |           |                |                 |                 | ●               |                 |     |           |
| Cooling system<br>Cooling water<br>Water filter<br>Bottom cock<br>Water pump impeller  | ○ ○       | □              |                 |                 | ○               | ●               |     |           |
| Electrical system<br>Each instrument<br>Glow plug<br>Starter motor, alternator and regulator<br>Alternator belt tension<br>Battery water level | ○         | ○              |                 | ○ ○             | ○               | ○               |     |           |

## 5 - PERIODICAL INSPECTIONS

### 5.1 - DAILY CHECKS BEFORE USING THE ENGINE

- 1 - Check engine and reverse gear oil level. Top up. No topping up required if oil level is close to upper level on dipstick.
- 2 - Check fuel level and open tank outlet valve.
- 3 - Open water inlet valve:
- 4 - Check pilot lights.

After starting, check oil pressure, water temperature and battery charge. The three pilot lamps should be extinguished and the horn should not sound.


- 5 - Check that the cooling water is flowing and for any irregularities in the exhaust gases, noise and vibrations.
- 6 - Check cooling water level.

### 5.2 - MAINTAINANCE AFTER FIRST 50 HOURS RUNNING

- 1 - Change engine and reverse gear oil. Proceed as indicated on pages 13 and 14.
- 2 - Change oil filter. Change as specified on page 14.


Fig 22

- 3 - Setting valve clearance. Carry out this operation when the engine is cold, as follows:
  - a) Remove the rocker arm cover, slacken off the rocker arm nut and while the adjusting screw is being turned, check the valve clearance with a gauge (Fig. 22).




b) With the no. 1 cylinder (box) piston at top dead centre on the compression stroke, set the clearance of the no. 1 cylinder inlet and exhaust valves. Likewise, with no. 2 cylinder piston at top dead centre, set the clearance of no. 2 cylinder inlet and exhaust valves.

Fig. 23



c) The positioning of no. 1 cylinder piston at top dead centre may be checked by mating marks on the distribution cover and the crank pulley (Fig. 23).

d) After adjusting, tighten the rocker arm nut well, whilst the adjusting screw is held against rotation.



**NOTE:**

The valve clearance must be adjusted after re-tightening the cylinder head holding screws (order of tightening illustrated in Fig. 24).

Fig. 24

Valve clearance (inlet-exhaust: 0,25 mm (0,0098 pulg)

Cylinder head torque: 4,2-4,7 Kgm (with washer).

4 - Alternator belt adjustment. Proceed as indicated on page 22.

5 - Re-tightening nuts and bolts.

Check the tightness of the engine and propeller shaft mounting bolts.

6 - Adjust engine slow running speed.

Check the engine slow running speed and adjust as indicated on page 17.

### 5.3 - MAINTAINANCE AFTER EVERY 100 HOURS RUNNING

1 - Change engine oil (see page 13).

2 - Change oil filter (see page 14).

3 - Clean fuel filter (see page 16).

4 - Drain fuel decanter filter.

Slacken off the wing nut located at the bottom of the glass bowl and allow all the accumulated water to run out. Re-tighten the wing nut and check for dripping.

5 - Clean water filter (see page 19).

6 - Adjust engine slow running speed (see page 18).

### 5.4 - MAINTAINANCE AFTER EVERY 200 HOURS RUNNING

1 - Change fuel filter. Proceed as indicated on page 16.

2 - Change decanter filter element.

Replace filter element together with gaskets.

Check that there is no fuel leak.

3 - Adjust alternator belt. (See page 22).

4 - Nozzle check.

Set the nozzle pressure to  $160^{+10}_{-0}$  Kg/cm<sup>2</sup> and remove any undesirable

injection conditions, including «after-dripping» (This operation should be effected by an Official SOLE Service Centre.

5 - Check battery water level.

Check this level, topping up with DISTILLED WATER, whenever required.

### **5.5 - MAINTAINANCE AFTER EVERY 400 HOURS RUNNING**

1 - Change air filter element. Proceed as indicated on page 14.

2 - Tighten up engine and propeller shaft mounting screws.

3 - Adjust valve clearance (see page 29).

4 - Check glow plugs.

Check whether glow plugs are burned out.

### **5.6 - MAINTAINANCE AFTER EVERY 800 HOURS RUNNING**

1 - Check compression.

- Remove glow plugs (or nozzles) and measure the pressure using a compression gauge.

Adjust as required if the pressure difference between cylinders is more than 2.5 kg/cm<sup>2</sup> or the pressure of each cylinder is below 26 kg/cm<sup>2</sup> (at 280 r.p.m.).

2 - Adjust fuel injection.

Have this operation done by a SOLE Service Centre.

3 - Check alternator and regulator.

- Regulate the voltage and the current using a circuit tester.

4 - Check starter motor pinion and engine flywheel ring gear.

Touch up any damaged bevel area with a file and replace if the part is completely damaged.

5 - Check water pump impeller.

Check that the impeller has no broken arm. If it has, proceed as indicated on page 21.

6 - Change the cooling system water.

Drain by opening the fresh water system drain cock (Fig. 15). After all the water has drained out, close the cock and refill with fresh, clean water up to the filler cap opening (Fig. 3).



## 6 - TROUBLESHOOTING

It is essential to detect and repair any breakdown or fault as soon as possible. Check and act in accordance with the instructions given below. If any repair requires a technical capacity beyond your reach, have it done by a SOLE, S. A. Authorized Service Centre.

### 1. Engine does not start

|   |   |
|---|---|
| Starter switch faulty.  | Check connections and contacts.   |
| Low starter motor torque.                                     | The battery is exhausted, the starter motor is faulty or the wiring is dirty or has a loose connection. |
| Inappropriate engine oil viscosity.                           | Check viscosity and change oil as required.   |
| Moving parts seized.  | Correct   |
| Still air inside.<br>No fuel in tank.<br>Fuel filter clogged. | Thoroughly purge.<br>Fill up.<br>Clean or replace.  |

## 2. Engine stops while running

|                      |                                  |
|----------------------|----------------------------------|
| Fuel tank empty.     | Fill up.                         |
| Fuel filter clogged. | Clean or replace.                |
| Air in fuel system.  | Retighten fuel pipe connections. |

## 3. Poor engine performance

|                      |                                  |
|----------------------|----------------------------------|
| Fuel filter clogged. | Clean or replace.                |
| Air in fuel system.  | Retighten fuel pipe connections. |

## 4. Inadequate oil pressure

|                             |          |
|-----------------------------|----------|
| Insufficient amount of oil. | Top up.  |
| Oil leaks from connections. | Repair.  |
| Oil pressure switch faulty. | Replace. |

## 5. Engine overheats

|                             |  |
|-----------------------------|--|
| Insufficient cooling water. | Check water pump impeller and replace.<br>Check bottom cock. |
| Dirty water filter.         | Clean.   |
| Cooling circuit clogged.    | Clean.   |
| Faulty thermocontact.       | Replace.   |

## 6. Battery charges poorly

|                                   |                    |
|-----------------------------------|--------------------|
| Incorrect belt tension.           | Adjust.            |
| Wiring faults.                    | Repair.            |
| Incorrect ammeter.<br>(if fitted) | Replace.           |
| Faulty battery.                   | Replace.           |
| Faulty regulator.                 | Repair or replace. |

## 7. Gears do not engage smoothly

|                                      |          |
|--------------------------------------|----------|
| Remote control poorly<br>adjusted.   | Adjust.  |
| Reverse gear control<br>maladjusted. | Adjust.  |
| Clutch cone worn.                    | Replace. |

## 7. SERVICE DETAILS

### 7.1 - SERVICE STANDARDS

- \* Valve clearance: 0.25 mm. (0.010'') with cold engine  
(both inlet and exhaust valves)
- \* Compression: 32 kg/cm<sup>2</sup> (454.4 psi) (320 R.P.M.)
- \* Oil capacity: Engine 1.8 litres  
Reverse gear 0.4 litres
- \* Injection order: 1 - 2
- \* Injection timing: 25° BTDC
  
- \* Nozzle pressure: 160  $\begin{matrix} +10 \\ -0 \end{matrix}$  kg/cm<sup>2</sup>


### 7.2 - TABLE OF TIGHTENING TORQUES

|  | kg-m    |         |
|--|---------|---------|
| * Cylinder head bolts (M.8)  | 4,2-4;7 |         |
| * Crank pulley nut:  | 15-20   |         |
| * Conrod big end cap nut (M.8)                                       | 3.2-3.5 |         |
| * Flywheel bolt (M.10)   | 6.5-7.0 |         |
| * Oil drain plug:  | 5.0-6.0 |         |
| * Oil filter:  | 1.1-1.3 |         |
| * Nozzle holder (against engine)                                     | 5-6     |         |
| * Nozzle holder retaining nut (M.22)                                 | 6-8     |         |
| * Nozzle holder ring nut (M.12)                                      | 4-5     |         |
| * Glow plug:   | 1.5-2.0 |         |
| * Reverse gear inlet clamp nut:                                      |         |         |
| * Reverse gear outlet clamp nut:                                     |         |         |
| * Starter "B" terminal nut (copper stud) (M.8)                       | 1.0-1.2 |         |
| General bolts and nuts Diameter of screw 4 (Head Mark) 7 (Head Mark) |         |         |
| M 6  | 0.3-0.5 | 0.8-1   |
| M 8  | 1.0-1.3 | 1.5-2.2 |
| M 10   | 1.8-2.5 | 3.0-4.2 |
| M 12   | 3.0-4.2 | 5.5-7.5 |

## CRANK CASE

| Item | Part no.   | Description                  | Quantity |
|------|------------|------------------------------|----------|
| 1-3  | 137 20 001 | BLOCK SUB ASSY, cylinder     | 1        |
| 2    | 135 20     | PLUG, expansion (40)         | 2        |
| 3    | 137 20 003 | BEARING, crankshaft STD      | 1        |
| —    | 137 20 004 | BEARING, crankshaft 0.25 US  | 1        |
| —    | 137 20 005 | BEARING, crankshaft 0.50 US  | 1        |
| —    | 137 20 006 | BEARING, crankshaft 0.75 US  | 1        |
| 4    | 137 20 008 | SHAFT, governor gear         | 1        |
| 5    | 137 20 009 | BUSHING, knock (6X9)         | 2        |
| 6    | 135 20 010 | BUSHING, knock (10X9)        | 2        |
| 7    | 131 20 011 | PLUG, taper (1/8)            | 2        |
| 8    | 131 20 014 | CONNECTOR                    | 1        |
| 10   | 137 20 019 | OIL SEAL                     | 1        |
| 11   | 137 20 020 | HOUSING, bearing             | 1        |
| 12   | 137 20 003 | BEARING, crankshaft STD      | 1        |
| —    | 137 20 004 | BEARING, crankshaft 0.25 US  | 1        |
| —    | 137 20 005 | BEARING, crankshaft 0.50 US  | 1        |
| —    | 137 20 006 | BEARING, crankshaft 0.75 US  | 1        |
| 13   | 131.24 047 | SHAFT, oil filter            | 1        |
| 14   | 131 20 026 | BOLT (4T:8X20)               | 3        |
| 15   | 137 20 024 | PLATE, rear                  | 1        |
| 16   | 132 27 002 | BOLT, with washer (4T:10X25) | 6        |
| 17   | 137 20 025 | WASHER, plain (10)           | 1        |
| 18   | 137 20 029 | GAUGE, oil level             | 1        |
| 19   | 137 20 028 | BOLT (4T:10X20)              | 4        |



# CRANK CASE



## OIL PAN & GEAR CASE

| Item | Part no.   | Description                 | Quantity |
|------|------------|-----------------------------|----------|
| 1-3  | 137 20 030 | PAN ASSY, oil               | 1        |
| 4    | 137 20 033 | GASKET, oil pan             | 1        |
| 5    | 131 23 005 | BOLT, with washer (7T:6X12) | 10       |
| 6    | 137 20 035 | CASE, gear                  | 1        |
| 7    | 137 20 036 | PIN, dowel                  | 2        |
| —    | 131 20 036 | PIN, dowel                  | 2        |
| 8    | 131 20 037 | PLUG, taper (1/2)           | 1        |
| 9    | 132 20 039 | OIL SEAL                    | 1        |
| 10   | 137 20 040 | GASKET, gear case           | 1        |
| 11   | 137 20 042 | BOLT (7T:6X20)              | 4        |
| 12   | 137 20 038 | BOLT (7T:6X55)              | 4        |
| 13   | 137 20 041 | BOLT (7T:6X75)              | 1        |
| 14   | 132 21 017 | PIPE                        | 1        |

# OIL PAN & GEAR CASE










## BLOCK

| Item | Part no.   | Description                      | Quantity |
|------|------------|----------------------------------|----------|
| 1    | 137 10 002 | BRACKET FRONT, right             | 1        |
| 2    | 137 10 003 | BRACKET FRONT, left              | 1        |
| 3    | 522 02 308 | SCREW                            | 4        |
| 4    | 530 33 010 | WASHER, spring $\phi$ 10         | 4        |
| 5    | 131 10 010 | BRACKET, rear                    | 2        |
| 6    | 131 10 017 | WASHER, plain                    | 6        |
| 7    | 137 10 009 | STUD, bracker rear               | 2        |
| 8    | 521 03 309 | SCREW                            | 4        |
| 9    | 511 23 010 | NUT                              | 6        |
| 10   | 522 02 308 | SCREW                            | 5        |
| 11   | 522 02 310 | SCREW                            | 1        |
| 12   | 530 38 010 | WASHER                           | 6        |
| 13   | 137 10 013 | BRACKET, transport rear          | 1        |
| 14   | 137 10 011 | INLET, manifold                  | 1        |
| 15   | 521 01 269 | SCREW                            | 1        |
| 16   | 137 10 012 | CLEANER ASSY, air                | 1        |
| 17   | 132 11 013 | ELEMENT, air cleane              | 1        |
| 18   | 131 11 037 | PIPE, rubber                     | 1        |
| 19   | 131 14 001 | FUEL PUMP, supply                | 1        |
| 20   | 131 14 002 | GASKET                           | 2        |
| 21   | 521 03 258 | SCREW                            | 2        |
| 22   | 530 38 008 | WASHER                           | 2        |
| 23   | 131 14 003 | BEND, inlet                      | 1        |
| 24   | 137 14 007 | PIPE, fuel pump to nozzle        | 1        |
| 25   | 137 14 008 | PIPE, fuel filter to pump        | 1        |
| 26   | 510 80 012 | CLAMP                            | 2        |
| 27   | 137 14 012 | BRACKET, fuel filter             | 1        |
| 28   | 511 20 006 | NUT                              | 1        |
| 29   | 147 14 001 | PUMP, oil extraction             | 1        |
| 30   | 137 14 002 | BRACKET, OIL PUMP                | 1        |
| 31   | 522 02 307 | SCREW                            | 2        |
| 32   | 530 33 010 | WASHER, spring $\phi$ 10         | 2        |
| 33   | 560 00 067 | WASHER, plain $\phi$ 13 (copper) | 3        |
| 34   | 132 14 021 | PIPE ASSY, oil pump              | 1        |
| 35   | 132 14 024 | COUPLING, oil pump               | 1        |
| 36   | 560 00 077 | WASHER, plain $\phi$ 18 (copper) | 2        |
| 37   | 131 11 039 | DRAIN COCK, block                | 1        |
| 38   | 137 10 010 | COUPLING PLATE, gear box         | 1        |
| 39   | 521 02 156 | SCREW                            | 8        |
| 40   | 530 33 006 | WASHER, spring $\phi$ 6          | 8        |


# BLOCK



## CYLINDER HEAD

| Item | Part no.   | Description           | Quantity |
|------|------------|-----------------------|----------|
| 1    | 135 21 003 | CAP ASSY, oil filler  | 1        |
| 2    | 137 21 007 | O-RING                | 1        |
| 3    | 137 21 001 | CYLINDER HEAD ASSY    | 1        |
| 4    | 137 21 002 | GUIDE, valve          | 1        |
| 5    | 132 20 012 | CAP, sealing (25)     | 4        |
| 6    | 137 21 004 | GASKET, cylinder head | 2        |
| 7    | 137 21 005 | WASHER, head bolt     | 1        |
| 8    | 137 21 006 | BOLT, cylinder head   | 10       |
| 9    | 137 21 012 | BOLT (7T:8X30)        | 10       |
| 10   | 137 21 009 | COVER ASSY, rocker    | 1        |
| 11   | 137 21 017 | PLUG, taper           | 1        |
| 12   | 137 21 010 | GASKET, rocker cover  | 1        |
| 13   | 132 21 016 | OIL SEAL              | 1        |
| 14   | 132 21 015 | WASHER                | 2        |
| 15   | 131 20 050 | NUT (7T:8)            | 2        |


# CYLINDER HEAD



## MAIN MOVING PARTS

| Item | Part no.   | Description                         | Quantity |
|------|------------|-------------------------------------|----------|
| 1    | 137 22 001 | PISTON & PIN ASSY STD               | 2        |
| —    | 137 22 002 | PISTON & PIN ASSY 0.25 OS           | 2        |
| —    | 137 22 003 | PISTON & PIN ASSY 0.50 OS           | 2        |
| —    | 137 22 004 | PISTON & PIN ASTY 0.75 OS           | 2        |
| 2    | 137 22 006 | RING SET, piston STD                | 2        |
| —    | 137 22 007 | RING SET, piston 0.25 OS            | 2        |
| —    | 137 22 008 | RING SET, piston 0.50 OS            | 2        |
| —    | 137 22 009 | RING SET, piston 0.75 OS            | 2        |
| 3-5  | 137 22 012 | ROD ASSY, connecting                | 2        |
| 4    | 132 22 013 | BOLT, connecting rod                | 4        |
| 5    | 132 22 011 | NUT, connecting rod                 | 4        |
| 6    | 137 22 014 | BEARING SET, connecting rod STD     | 2        |
| —    | 137 22 015 | BEARING SET, connecting rod 0.25 US | 2        |
| —    | 137 22 016 | BEARING SET, connecting rod 0.50 US | 2        |
| —    | 137 22 017 | BEARING SET, connecting rod 0.75 US | 2        |
| 7    | 137 22 018 | CRANKSHAFT                          | 1        |
| 8    | 137 22 019 | PLATE, crankshaft                   | 1        |
| 9    | 132 22 020 | KEY, woodruff (5X9)                 | 1        |
| 10   | 137 22 021 | GEAR, crankshaft                    | 1        |
| 11   | 137 22 022 | PIECE DISTANCE                      | 1        |
| 12   | 137 22 023 | WASHER, plain (24)                  | 1        |
| 13   | 137 22 024 | PULLEY, crankshaft                  | 1        |
| 14   | 137 22 025 | WASHER, plain (24)                  | 1        |
| 15   | 131 22 026 | NUT (4T:24)                         | 1        |
| 16   | 137 22 027 | FLYWHEEL ASSY                       | 1        |
| 17   | 137 22 029 | GEAR, ring                          | 1        |
| 18   | 137 22 030 | WASHER, tongued                     | 1        |
| 19   | 137 22 031 | BOLT, especial                      | 4        |






# MAIN MOVING PARTS



## COOLING SYSTEM

| Item | Part no.   | Description                      | Quantity |
|------|------------|----------------------------------|----------|
| 1    | 131 11 023 | WED EXHAUST BEND                 | 1        |
| 2    | 151 13 043 | GASKET                           | 1        |
| 3    | 135 13 016 | STUD                             | 4        |
| 4    | 530 33 008 | WASHER, spring $\varnothing$ 8   | 4        |
| 5    | 541 20 008 | NUT                              | 4        |
| 6    | 128 11 056 | PIPE                             | 1        |
| 7    | 131 11 037 | PIPE, rubber                     | 1        |
| 8    | 580 86 017 | CLAMP                            | 2        |
| 9    | 137 11 001 | WATER COOLER                     | 1        |
| 10   | 135 11 002 | CAP FRONT, cooler                | 1        |
| 11   | 135 11 003 | CAP REAR, cooler                 | 1        |
| 12   | 137 11 004 | PIPE, cooler                     | 1        |
| 13   | 135 11 008 | O-RING, $\varnothing$ 45x54x4, 5 | 1        |
| 14   | 135 11 010 | O-RING $\varnothing$ 45x51x3     | 1        |
| 15   | 252 10 417 | O-RING $\varnothing$ 47x52x2, 5  | 1        |
| 16   | 137 21 035 | GASKET, exhaust manifold         | 2        |
| 17   | 137 11 009 | STUD                             | 4        |
| 18   | 530 33 008 | WASHER, spring $\varnothing$ 8   | 4        |
| 19   | 541 20 008 | NUT                              | 4        |
| 20   | 560 00 057 | WASHER, plain (copper)           | 4        |
| 21   | 132 11 016 | NUT                              | 2        |
| 22   | 131 11 038 | DRAIN COCK, water cooler         | 1        |
| 23   | 560 00 062 | WASHER, plain (copper)           | 1        |
| 24   | 147 11 011 | NUT                              | 1        |
| 25   | 151 11 002 | FILLER CAP PIPE                  | 1        |
| 26   | 147 11 003 | FILLER CAP                       | 1        |
| 27   | 137 11 020 | FITTING, thermostat              | 1        |
| 28   | 132 11 054 | GASKET                           | 2        |
| 29   | 135 11 021 | FITTING, water outlet            | 1        |
| 30   | 521 01 263 | SCREW                            | 2        |
| 31   | 530 38 008 | WASHER                           | 2        |
| 32   | 137 11 022 | PIPE                             | 1        |
| 33   | 540 82 025 | HOSE, clamp                      | 2        |
| 34   | 137 11 025 | PIPE, water pump to cooler       | 1        |
| 35   | 137 11 017 | PIPE, rubber                     | 1        |
| 36   | 540 82 025 | HOSE, clamp                      | 4        |
| 37   | 137 11 026 | ELBOW, water pump inlet          | 1        |
| 38   | 128 11 056 | ELBOW, water pump outlet         | 2        |

# COOLING SYSTEM





## SEA COOLING SYSTEM

| Item | Part no.   | Description                | Quantity |
|------|------------|----------------------------|----------|
| 1    | 137 11 028 | PIPE, water pump to cooler | 1        |
| 2    | 580 86 017 | HOSE, rubber               | 2        |
| 3    | 121 11 026 | MAINTANANCE, water pump    | 1        |
| 4    | 321 11 023 | GASKET, sea water pump     | 1        |
| 5    | 511 02 156 | SCREW                      | 2        |
| 6    | 570 00 353 | WASHER, aluminium          | 2        |
| —    | 321 11 000 | SEA WATER PUMP ASSY        | 1        |
| 7    | 553 07 104 | SCREW                      | 6        |
| 8    | 321 11 002 | COVER, water pump          | 1        |
| 9    | 553 07 102 | SCREW                      | 1        |
| 10   | 321 11 026 | DISC, seal holdind         | 1        |
| 11   | 321 11 008 | IMPELLER ASSY              | 1        |
| 12   | 321 11 001 | BODY, sea water pump       | 1        |
| 13   | 321 11 010 | SHAFT, pump                | 1        |
| 14   | 312 11 016 | BEARING, ball              | 1        |
| 15   | 321 11 020 | SEAL, lip                  | 2        |
| 16   | 321 11 003 | GASKET                     | 1        |
| 17   | 321 11 005 | CAM                        | 1        |
| 18   | 121 11 078 | ELBOW, water inlet         | 1        |
| 19   | 121 11 082 | ELBOW, water outlet        | 1        |

# SEA COOLING SYSTEM



1



2



3



4




5



6



7



8



9



10



11



12




13



14



15



16



17



18




19

## TIMMING PARTS

| Item | Part no.   | Description                 | Quantity |
|------|------------|-----------------------------|----------|
| 1    | 137 22 035 | CAMSHAFT                    | 1        |
| 2    | 131 22 036 | KEY, woodruff (5X16)        | 1        |
| 3    | 137 22 037 | GEAR, camshaft              | 1        |
| 4    | 137 22 040 | TAPPET                      | 4        |
| 5    | 137 22 041 | ROD, push                   | 4        |
| —    | 137 22 061 | ROD, push                   | 4        |
| 6    | 137 22 042 | ARM, rocker                 | 4        |
| 7    | 137 22 044 | SCREW, adjusting            | 4        |
| 8    | 137 22 045 | NUT, jam (10)               | 4        |
| 9    | 137 22 046 | SHAFT ASSY, rocker          | 1        |
| 10   | 137 22 047 | SPRING, rocker shaft        | 1        |
| 11   | 137 22 048 | STAY, rocker                | 2        |
| 12   | 137 22 051 | SNAP RING, (12)             | 2        |
| 13   | 131 21 025 | WASHER, plain (8)           | 2        |
| 14   | 137 22 053 | BOLT, rocker stay           | 2        |
| 15   | 132 22 054 | SEAL, valve stem            | 4        |
| 16   | 137 22 055 | VALVE, inlet                | 2        |
| 17   | 137 22 056 | VALVE, exhaust              | 2        |
| 18   | 137 22 057 | SPRING, valve               | 4        |
| 19   | 137 22 058 | RETAINER, valve spring      | 4        |
| 20   | 132 22 059 | LOCK, valve spring retainer | 8        |


# TIMMING PARTS



## FUEL SUPPLY PARTS

| Item | Part no.   | Description                      | Quantity |
|------|------------|----------------------------------|----------|
| 1    | 131 24 001 | WASHER, seal                     | 2        |
| 2    | 131 24 002 | COLLAR, union                    | 1        |
| 3    | 137 25 001 | PUMP ASSY, fuel injection        | 1        |
| 4    | 131 24 003 | SHIM, adjusting 0.2t             | C        |
| —    | 131 24 004 | SHIM, adjusting 0.3t             | C        |
| —    | 131 24 005 | SHIM, adjusting 0.4t             | C        |
| —    | 131 24 006 | SHIM, adjusting 0.5t             | C        |
| —    | 131 24 007 | SHIM, adjusting 0.6t             | C        |
| —    | 131 24 008 | SHIM, adjusting 0.7t             | C        |
| —    | 131 24 009 | SHIM, adjusting 0.8t             | C        |
| —    | 131 24 010 | SHIM, adjusting 0.9t             | C        |
| —    | 131 24 011 | SHIM, adjusting 1.0t             | C        |
| 5    | 131 24 012 | BOLT, (4T:8X20)                  | 4        |
| 6    | 137 26 001 | NOZZLE & HOLDER ASSY             | 2        |
| 7    | 131 24 013 | GASKET                           | 2        |
| 8    | 137 24 015 | PIPE ASSY, fuel injection (No.1) | 1        |
| 9    | 137 24 016 | PIPE ASSY, fuel injection (No.2) | 1        |
| 10   | 131 24 018 | CLAMP (A)                        | 1        |
| 11   | 131 24 017 | CLAMP (B)                        | 1        |
| 12   | 132 24 024 | BOLT, with washer (4T:6X25)      | 1        |
| 13   | 131 24 020 | FILTER ASSY, fuel                | 1        |
| 14   | 131 24 021 | CLAMP, filter                    | 1        |
| 15   | 131 23 005 | BOLT, with washer (7T:6X12)      | 1        |
| 16   | 131 24 023 | WASHER, plain (6)                | 1        |
| 20   | 137 24 025 | PIPE ASSY, fuel return           | 1        |
| 21   | 137 24 026 | JOINT                            | 1        |
| 22   | 137 24 027 | CLAMP, hose                      | 4        |


# FUEL SUPPLY PARTS



## FUEL INJECTION PUMP

| Item | Part no.   | Description              | Quantity |
|------|------------|--------------------------|----------|
| 1-27 | 137 25 001 | PUM ASSY, fuel injection | 1        |
| 1    | 131 25 005 | HOUSING SUB ASSY         | 1        |
| 2    | 137 25 004 | HOLDER, delivery valve   | 2        |
| 3    | 131 25 006 | SPRING, delivery valve   | 2        |
| 4    | 131 25 007 | GASKET, delivery valve   | 2        |
| 5    | 131 25 008 | VALVE SUB ASSY           | 2        |
| 6    | 137 25 009 | ELEMENT SUB ASSY         | 2        |
| 7    | 131 25 010 | SLEEVE, control          | 2        |
| 8    | 131 25 011 | SEAT, spring upper       | 2        |
| 9    | 131 25 012 | SPRING, plunger          | 2        |
| 10   | 131 25 021 | TAPPET SUB ASSY          | 2        |
| 11   | 137 25 006 | RACK ASSY, control       | 1        |
| 12   | 131 25 013 | SEAT, spring             | 2        |
| 13   | 131 25 033 | O-RING                   | 2        |
| 14   | 131 25 022 | PIN, tappet guide        | 2        |
| 15   | 131 25 023 | PLATE                    | 1        |
| 16   | 131 25 030 | PLATE ASSY, adjusting    | 1        |
| 17   | 131 25 028 | BOLT, with washer        | 1        |
| 18   | 131 25 026 | SCREW, air breather      | 1        |
| 19   | 137 25 027 | SCREW, follow            | 1        |
| 20   | 131 25 025 | WASHER                   | 1        |
| 21   | 131 25 014 | SHIM, adjusting t = 0.6  | C        |
| —    | 131 25 015 | SHIM, adjusting t = 0.2  | C        |
| —    | 131 25 016 | SHIM, adjusting t = 0.3  | C        |
| —    | 131 25 017 | SHIM, adjusting t = 0.4  | C        |
| —    | 131 25 018 | SHIM, adjusting t = 0.5  | C        |
| —    | 131 25 019 | SHIM, adjusting t = 0.25 | C        |
| —    | 131 25 020 | SHIM, adjusting t = 0.35 | C        |
| —    | 137 25 021 | SHIM, adjusting t = 0.45 | C        |

# FUEL INJECTION PUMP






## FUEL INJECTION PUMP

| Item | Part no.   | Description              | Quantity |
|------|------------|--------------------------|----------|
| —    | 137 25 022 | SHIM, adjusting t = 0.55 | C        |
| —    | 137 25 023 | SHIM, adjusting t = 0.65 | C        |
| 22   | 135 25 031 | SPRING, return           | 1        |
| 23   | 131 25 032 | PIN, split               | 1        |
| 24   | 131 25 034 | WASHER, plate t = 0.1    | C        |
| —    | 131 25 037 | WASHER, plate t = 0.2    | C        |
| —    | 131 25 035 | WASHER, plate t = 0.25   | C        |
| —    | 131 25 036 | WASHER, plate t = 0.5    | C        |
| 25   | 137 25 043 | STOPPER                  | C        |
| —    | 137 25 044 | STOPPER                  | C        |
| —    | 135 25 045 | STOPPER                  | C        |
| —    | 137 25 045 | STOPPER                  | C        |
| —    | 135 25 046 | STOPPER                  | C        |
| —    | 137 25 046 | STOPPER                  | C        |
| —    | 131 25 038 | STOPPER                  | C        |
| —    | 137 25 038 | STOPPER                  | C        |
| —    | 131 25 039 | STOPPER                  | C        |
| —    | 137 25 039 | STOPPER                  | C        |
| —    | 131 25 040 | STOPPER                  | C        |
| —    | 137 25 040 | STOPPER                  | C        |
| —    | 131 25 041 | STOPPER                  | C        |
| —    | 137 25 041 | STOPPER                  | C        |
| —    | 131 25 042 | STOPPER                  | C        |
| 26   | 137 25 002 | PLATE, name              | 1        |
| 27   | 131 25 003 | RIVET                    | 2        |


# FUEL INJECTION PUMP



## NOZZLE & NOZZLE HOLDER

| Item | Part no.   | Description          | Quantity |
|------|------------|----------------------|----------|
| 1-10 | 137 26 001 | NOZZLE & HOLDER ASSY | 2        |
| 1    | 137 26 009 | NUT, hexagon         | 2        |
| 2    | 137 26 005 | RING SUB ASSY        | 2        |
| 3    | 137 26 008 | WASHER               | 2        |
| 4    | 137 26 002 | BODY SUB ASSY        | 2        |
| 5    | 137 26 010 | WASHER 1.0t          | C        |
| —    | 137 26 011 | WASHER 1.05t         | C        |
| —    | 137 26 012 | WASHER 1.1t          | C        |
| —    | 137 26 013 | WASHER 1.15t         | C        |
| —    | 137 26 014 | WASHER 1.2t          | C        |
| —    | 137 26 015 | WASHER 1.25t         | C        |
| —    | 137 26 016 | WASHER 1.3t          | C        |
| —    | 137 26 017 | WASHER 1.35t         | C        |
| —    | 137 26 018 | WASHER 1.4t          | C        |
| —    | 137 26 019 | WASHER 1.45t         | C        |
| —    | 137 26 020 | WASHER 1.5t          | C        |
| —    | 137 26 021 | WASHER 1.55t         | C        |
| —    | 137 26 022 | WASHER 1.6t          | C        |
| —    | 137 26 023 | WASHER 1.65t         | C        |
| —    | 137 26 024 | WASHER 1.7t          | C        |
| —    | 137 26 025 | WASHER 1.75t         | C        |
| —    | 137 26 026 | WASHER 1.8t          | C        |
| —    | 137 26 027 | WASHER 1.85t         | C        |
| —    | 137 26 028 | WASHER 1.9t          | C        |
| —    | 137 26 029 | WASHER 1.95t         | C        |
| 6    | 137 26 004 | SPRING, pressure     | 2        |
| 7    | 131 26 003 | PIN, pressure        | 2        |
| 8    | 131 26 007 | PIECE, distance      | 2        |
| 9    | 131 26 018 | NOZZLE ASSY          | 2        |
| 10   | 137 26 006 | NUT, retaining       | 2        |


# NOZZLE & NOZZLE HOLDER



## GOVERNOR PARTS

| Item | Part no.   | Description                 | Quantity |
|------|------------|-----------------------------|----------|
| 1    | 137 23 004 | SLEEVE                      | 1        |
| 2    | 137 23 001 | GEAR ASSY, governor         | 1        |
| 3    | 137 23 002 | SNAP RING (18)              | 1        |
| 4    | 137 23 003 | WEIGHT ASSY, governor       | 1        |
| 5    | 137 23 006 | SHAFT ASSY, sliding         | 1        |
| 6    | 137 23 005 | STOPPER                     | 2        |
| 7    | 137 23 008 | BOLT, with washer (7T:6X25) | 1        |
| 8    | 137 23 011 | WASHER                      | 1        |
| 9    | 131 23 016 | SHAFT, governor             | 1        |
| 10   | 137 23 007 | LEVER, fork                 | 1        |
| 11   | 131 23 008 | BOLT, with washer (7T:6X14) | 1        |
| 12   | 131 23 009 | PIN, grooved                | 2        |
| 13   | 131 23 015 | LEVER, governor spring      | 1        |
| 14   | 131 20 049 | WASHER, spring (8)          | 2        |
| 15   | 131 23 013 | NUT, jam (4T:8)             | 2        |
| 16   | 137 23 014 | LEVER ASSY, speed control   | 1        |
| 17   | 137 23 015 | LEVER (C), governor         | 1        |
| 18   | 137 23 016 | SPRING, governor            | 1        |
| 19   | 131 23 017 | BOLT, high speed set        | 1        |
| 20   | 131 23 018 | NUT (4T:6)                  | 1        |
| 21   | 131 23 020 | WIRE                        | 1        |
| 22   | 131 23 019 | METAL, sealing              | 1        |
| 23   | 131 23 021 | O-RING (7)                  | 1        |


# GOVERNOR PARTS



## LUBRICATING PARTS

| Item | Part no.   | Description                 | Quantity |
|------|------------|-----------------------------|----------|
| 1-9  | 137 24 040 | OIL PUMP ASSY               | 1        |
| 1    | 137 24 046 | BODY, oil pump              | 1        |
| 2    | 137 24 049 | O-RING                      | 1        |
| 3    | 137 24 042 | ROTOR ASSY                  | 1        |
| 4    | 137 24 061 | COVER, OIL PUMP             | 1        |
| 5    | 137 24 043 | VALVE, relief               | 1        |
| 6    | 137 24 044 | SPRING, oil relief          | 1        |
| 7    | 131 24 046 | GASKET (10)                 | 1        |
| 8    | 137 24 045 | PLUG, relief valve          | 1        |
| 9    | 131 20 011 | PLUG, taper (PT-1/8)        | 2        |
| 10   | 137 24 041 | GASKET, pump body           | 1        |
| 11   | 137 24 050 | BOLT, with washer (7T:6X40) | 3        |
| 12   | 137 20 042 | BOLT (7T:6X20)              | 1        |
| 13   | 131 24 051 | FILTER ASSY, oil            | 1        |
| 14   | 137 24 052 | SCREEN ASSY, oil            | 1        |
| 15   | 131 24 053 | NUT, jam (4T:12)            | 1        |
| 16   | 131 24 001 | WASHER, seal (12)           | 1        |
| 17   | 137 24 057 | PIPE ASSY, oil              | 1        |
| 18   | 131 24 058 | BOLT, eye (8)               | 1        |
| 19   | 131 24 059 | GASKET (8)                  | 2        |
| 20   | 131 24 060 | SWITCH ASSY, oil pressure   | 1        |

# LUBRICATING PARTS






## COOLING PARTS

| Item | Part no.   | Description                 | Quantity |
|------|------------|-----------------------------|----------|
| 2    | 132 21 021 | PULLEY, water pump          | 1        |
| 3    | 131 23 005 | BOLT, with washer (7T:6X12) | 4        |
| 4    | 137 21 028 | BELT, fan (HM POC = 710)    | 1        |
| 5    | 137 21 020 | PUMP ASSY, water            | 1        |
| 6    | 137 21 022 | GASKET, water pump          | 1        |
| 7    | 137 21 023 | BOLT (7T:6X30)              | 1        |
| 8    | 137 21 024 | BOLT (7T:6X65)              | 3        |
| 9    | 137 21 025 | BOLT (7T:6X80)              | 1        |
| 13   | 131 27 080 | SWITCH, thermo (111°C)      | 1        |
| 14   | 132 21 027 | THERMOSTAT (71)             | 1        |


COOLING PARTS



## ALTERNATOR

| Item | Part no.   | Description         | Quantity |
|------|------------|---------------------|----------|
| 1-17 | 136 27 010 | ALTERNATOR ASSY     | 1        |
| †    | 132 27 051 | NUT, set            | 1        |
| 2    | 136 27 052 | PULLEY ASSY         | 1        |
| 3    | 136 27 053 | BOLT SET, through   | 1        |
| 4    | 136 27 054 | BRACKET ASSY, front | 1        |
| 5    | 132 27 055 | SCREW SET           | 1        |
| 6    | 136 27 056 | BEARING, front      | 1        |
| 7    | 132 27 057 | ROTOR ASSY          | 1        |
| 8    | 132 27 058 | BEARING, rear       | 1        |
| 9    | 136 27 059 | STATOR ASSY         | 1        |
| 10   | 136 27 060 | BRACKET ASSY, rear  | 1        |
| 11   | 136 27 061 | TERMINAL SET        | 1        |
| 12   | 136 27 016 | REGULATOR ASSY      | 1        |
| 13   | 134 27 065 | BRUSH               | 2        |
| 14   | 132 27 066 | SPRING BRUSH        | 2        |
| 15   | 136 27 067 | RECTIFIER           | 1        |
| 16   | 136 27 068 | CONDENSER ASSY      | 1        |
| 17   | 136 27 069 | BOLT, with washer   | 1        |


# ALTERNATOR



## STARTER

| Item | Part no.   | Description                     | Quantity |
|------|------------|---------------------------------|----------|
| 1-19 | 137 27 001 | STARTER ASSY (M003T32481:0.9KW) | 1        |
| 1,2  | 137 27 101 | SCREW SET                       | 1        |
| 3    | 137 27 102 | LEVER ASSY                      | 1        |
| 4    | 131 27 103 | SPRING SET                      | 1        |
| 5    | 131 27 104 | SWITCH ASSY                     | 1        |
| 6    | 137 27 114 | BOLT SET                        | 1        |
| 7    | 137 27 106 | BRACKET ASSY, front             | 1        |
| 8    | 137 27 107 | BEARING, front                  | 1        |
| 9    | 131 27 108 | STOPPER SET                     | 1        |
| 10   | 137 27 109 | CLUTCH, over running            | 1        |
| 11   | 137 27 111 | ARMATURE                        | 1        |
| 12   | 135 27 112 | WASHER SET                      | 1        |
| 13   | 137 27 113 | YOKE ASSY                       | 1        |
| 14   | 137 27 116 | BRUSH                           | 2        |
| 15   | 137 27 117 | HOLDER ASSY, brush              | 1        |
| 16   | 137 27 119 | BRUSH                           | 1        |
| 17   | 131 27 118 | SPRING, brush                   | 3        |
| 18   | 135 27 120 | BRACKET ASSY, rear              | 1        |
| 19   | 131 27 121 | BEARING, rear                   | 1        |


# STARTER



## ELECTRICAL EQUIPMENT


| Item | Part no.   | Description                    | Quantity |
|------|------------|--------------------------------|----------|
| 1    | 137 27 001 | STARTER ASSY                   | 1        |
| 2    | 131 27 012 | SCREW                          | 2        |
| 3    | 136 27 010 | ALTERNADOR, ASSY               | 1        |
| 4    | 137 17 010 | PULLEY, alternator             | 1        |
| 5    | 137 17 011 | BRACKET, alternator            | 1        |
| 6    | 137 27 008 | SCREW                          | 1        |
| 7    | 521 01 262 | SCREW                          | 1        |
| 8    | 510 30 008 | WASHER, plain $\varnothing$ 8  | 2        |
| 9    | 530 33 008 | WASHER, SPRING $\varnothing$ 8 | 2        |
| 10   | 521 20 008 | NUT                            | 2        |
| 11   | 137 17 012 | BRACE, alternator              | 1        |
| 12   | 521 02 257 | SCREW                          | 1        |
| 13   | 530 33 008 | WASHER, spring $\varnothing$ 8 | 1        |
| 14   | 510 30 008 | WASHER, plain $\varnothing$ 8  | 1        |
| 15   | 137 17 013 | V BELT, alternator             | 1        |
| 16   | 530 33 005 | WASHER, spring $\varnothing$ 5 | 1        |
| 17   | 511 20 005 | NUT                            | 1        |
| 18   | 530 33 008 | WASHER, spring $\varnothing$ 5 | 1        |
| 19   | 521 20 008 | NUT                            | 1        |
| 20   | 137 27 017 | GLOW, plug                     | 2        |
| 21   | 137 27 018 | WIRE, glow plug lead           | 1        |
| 22   | 131 17 001 | STOP, selenoid                 | 1        |
| 23   | 137 17 002 | STUD, selenoid                 | 1        |
| 24   | 137 17 003 | BRACKET, selenoid              | 1        |
| 25   | 521 01 169 | SCREW                          | 2        |
| 26   | 510 30 006 | WASHER, plain $\varnothing$ 6  | 2        |
| 27   | 530 33 006 | WASHER, spring $\varnothing$ 6 | 2        |
| 28   | 521 20 006 | NUT                            | 2        |
| 29   | 511 02 106 | SCREW                          | 4        |
| 30   | 510 30 005 | WASHER, plain $\varnothing$ 5  | 4        |
| 31   | 530 33 005 | WASHER, spring $\varnothing$ 5 | 4        |
| 32   | 511 20 005 | NUT                            | 4        |
| 33   | 511 08 052 | SCREW                          | 1        |
| 34   | 146 19 040 | SPRING, return selenoid        | 1        |

# ELECTRICAL EQUIPMENT




1

2



3



4



5



6



7




8



9



10



11




12



13



14



15



16



17



18




19



20




21



22



23



24



25



26



27



28



29



30



31



32



33




34




## ELECTRICAL EQUIPMENT

| Item | Part no.   | Description           | Quantity |
|------|------------|-----------------------|----------|
| —    | 609 37 000 | ELECTRICAL PANEL ASSY | 1        |
| 1    | 609 31 001 | PANEL                 | 1        |
| 2    | 609 34 010 | TACHOMETTER           | 1        |
| 3    | 609 00 031 | SWITCH, starting      | 1        |
| 4    | 609 00 040 | SWITCH, stop          | 1        |
| 5    | 609 00 045 | BULB, 12 V.           | 3        |
| 6    | 609 00 050 | LAMP, oil press       | 1        |
| 7    | 609 00 051 | LAMP, battery charge  | 1        |
| 8    | 609 00 052 | LAMP, water temp.     | 1        |
| 9    | 609 00 060 | ALARM, switch         | 1        |
| 10   | 609 37 095 | LAMP, glow            | 1        |
| 11   | 609 00 110 | DIODE                 | 1        |
| —    | 609 00 115 | FUSE 3 A.             | 2        |
| 12   | 609 37 200 | CABLES, electrical    | 1        |
| 13   | 609 00 116 | FUSE 40 A.            | 1        |
| 14   | 580 88 272 | CLAMP                 | 1        |
| 15   | 580 88 271 | CLAMP                 | 2        |


# ELECTRICAL EQUIPMENT



1



2




3



4



5




6



7



8



9



10




11



12



13



14




15

## REMOTE CONTROL

| Item | Part no.   | Description                    | Quantity |
|------|------------|--------------------------------|----------|
| 1    | 137 19 004 | BRACKET, engine control        | 1        |
| 2    | 135 17 003 | STUD                           | 2        |
| 3    | 510 30 006 | WASHER, plain $\varnothing$ 6  | 2        |
| 4    | 530 33 006 | WASHER, spring $\varnothing$ 6 | 2        |
| 5    | 511 20 006 | NUT                            | 2        |
| 6    | 147 19 013 | CLAMP, cable                   | 1        |
| 7    | 553 07 105 | SCREW                          | 2        |
| 8    | 131 19 015 | BRACKET, gear box control      | 1        |
| 9    | 121 19 020 | BRACKET, gear box control      | 1        |
| 10   | 121 19 021 | BRACKET, clamp                 | 1        |
| 11   | 511 02 157 | SCREW                          | 4        |
| 12   | 510 30 006 | WASHER, plain $\varnothing$ 6  | 4        |
| 13   | 530 33 006 | WASHER, spring $\varnothing$ 6 | 4        |
| 14   | 511 20 006 | NUT                            | 4        |
| 15   | 147 19 013 | CLAMP, cables                  | 1        |
| 16   | 553 07 105 | SCREW                          | 2        |
| 17   | 147 19 026 | YOKE, gear control             | 1        |
| 18   | 147 19 027 | PIN                            | 1        |
| 19   | 510 30 005 | WASHER, plain $\varnothing$ 5  | 2        |
| 20   | 510 51 107 | PIN                            | 1        |
| 21   | 131 19 003 | YOKE, gas control              | 1        |
| 22   | 147 19 034 | PIN                            | 1        |
| 23   | 510 30 063 | WASHER, plain $\varnothing$ 6  | 2        |
| 24   | 510 51 107 | PIN                            | 1        |
| 25   | 131 17 006 | TOP, stop                      | 1        |
| 26   | 530 33 006 | WASHER, spring                 | 1        |
| 27   | 511 20 006 | NUT                            | 1        |
| 28   | 137 19 006 | BRACKET, low speed             | 1        |
| 29   | 131 19 005 | SPRING, control                | 1        |
| 30   | 511 02 160 | SCREW                          | 1        |
| 31   | 510 31 006 | WASHER, plain $\varnothing$ 6  | 1        |
| 32   | 511 20 006 | NUT                            | 2        |

# REMOTE CONTROL



1



2



3



4



5




6




7



8



9



10



11



12



13



14



15



16



17



18



19



20



21



22



23



24



25



26



27



28



29



30



31




32

## REPAIR GASKET KIT

| Item | Part no.   | Description                | Quantity |
|------|------------|----------------------------|----------|
| 1-27 | 137 20 101 | GASKET KIT                 | 1        |
| 1    | 137 20 019 | OIL SEAL, crank shaft rear | 1        |
| 2    | 132 20 039 | OIL SEAL                   | 1        |
| 3    | 137 20 040 | GASKET, gear case          | 1        |
| 5    | 137 20 033 | GASKET, oil pan            | 1        |
| 6    | 132 22 054 | SEAL, valve stem           | 4        |
| 7    | 137 21 004 | GASKET, cylinder head      | 1        |
| 8    | 137 21 010 | GASKET, rocker cover       | 1        |
| 9    | 131 24 001 | WASHER, seal               | 3        |
| 10   | 131 25 007 | GASKET, delivery valve     | 2        |
| 11   | 131 25 033 | O-RING                     | 2        |
| 12   | 137 24 041 | GASKET, oil pump           | 1        |
| 13   | 137 21 022 | GASKET, water pump         | 1        |
| 15   | 131 24 013 | GASKET, nazzle holder      | 2        |
| 16   | 137 21 035 | GASKET, exhaust manifold   | 2        |
| 18   | 131 24 003 | SHIM, adjusting t = 0.2    | 1        |
| —    | 131 24 004 | SHIM, adjusting t = 0.3    | 1        |
| —    | 131 24 005 | SHIM, adjusting t = 0.4    | 1        |
| —    | 131 24 009 | SHIM, adjusting t = 0.8    | 1        |
| 19   | 132 21 016 | OIL SEAL                   | 2        |
| 20   | 137 21 007 | O-RING (30)                | 1        |
| 21   | 131 25 025 | WASHER                     | 1        |
| 22   |            | GASKET (10)                | 2        |
| 23   |            | GASKET (12)                | 1        |
| 24   | 137 24 049 | O-RING                     | 1        |
| 25   | 131 24 046 | GASKET                     | 1        |
| 26   | 137 24 059 | GASKET                     | 2        |
| 27   | 131 23 021 | O-RING                     | 1        |


# REPAIR GASKET KIT




## GEAR-BOX

| Item | Part no.   | Description                | Quantity |     |
|------|------------|----------------------------|----------|-----|
|      |            |                            | 2:1      | 3:1 |
| 1/53 | 223 13 000 | RONIM III GEAR BOX 2:1 RED | 1        | —   |
| 1/53 | 223 15 000 | RONIM III GEAR BOX 3:1 RED | —        | 1   |
| 1    | 223 10 021 | HOUSING, front             | 1        | —   |
| 1    | 223 15 021 | HOUSING, front             | —        | 1   |
| 2    | 223 13 002 | HOUSING, rear              | 1        | —   |
| 2    | 223 15 002 | HOUSING, rear              | —        | 1   |
| 3    | 223 10 003 | GASKET, housing            | 1        | 1   |
| 4    | 223 10 035 | FLANGE, input              | 1        | 1   |
| 5    | 222 10 007 | PIN                        | 2        | 2   |
| 6    | 223 10 008 | PLUG, oil level            | 1        | 1   |
| 7    | 252 10 010 | O'RING, plug               | 1        | 1   |
| 8    | 223 10 011 | PLUG, drain                | 1        | 1   |
| 9    | 223 13 101 | SHAFT, input.              | 1        | —   |
| 9    | 223 15 101 | SHAFT, input.              | —        | 1   |
| 10   | 222 10 103 | OIL SEAL                   | 2        | 1   |
| 10   | 224 10 223 | OIL SEAL                   | —        | 1   |
| 11   | 222 10 104 | BALL BEARING, front        | 2        | 1   |
| 11   | 224 10 224 | BALL BEARING, front        | —        | 1   |
| 12   | 223 10 102 | COVER, front               | 1        | 1   |
| 13   | 223 10 105 | GASKET, front cover        | 1        | 1   |
| 14   | 223 10 106 | NEEDLE BEARING, rear       | 2        | 2   |
| 15   | 223 10 201 | SHAFT, output              | 1        | —   |
| 15   | 224 15 201 | SHAFT, output              | —        | 1   |
| 16   | 222 10 202 | CLUTCH CONE                | 1        | 1   |
| 17   | 223 13 203 | GEAR, front                | 1        | —   |
| 17   | 223 15 203 | GEAR, front                | —        | 1   |
| 18   | 222 10 204 | NEEDLE BEARING             | 2        | 1   |
| 18   | 224 10 204 | NEEDLE BEARING             | —        | 1   |
| 19   | 222 10 205 | RING, bearing IR20x25x17   | 2        | 1   |
| 19   | 224 10 205 | RING, bearing IR20x25x7    | —        | 1   |
| 20   | 223 10 207 | RING, bearing LR20x25x12,5 | 1        | 1   |
| 21   | 223 10 208 | COVER, rear                | 1        | —   |
| 21   | 223 15 208 | COVER, rear                | —        | 1   |
| 22   | 223 10 209 | GASKET, cove rear          | 1        | 1   |
| 23   | 223 10 210 | GEAR, rear                 | 1        | —   |
| 23   | 224 15 210 | GEAR, rear                 | —        | 1   |
| 24   | 223 10 217 | SPACER, gear rear          | 2        | 1   |
| 24   | 224 10 217 | SPACER, gear rear          | —        | 1   |
| 25   | 223 10 218 | SPACER, bearing rear       | 2        | 1   |
| 25   | 224 10 218 | SPACER, bearing rear       | —        | 1   |
| 26   | 222 10 219 | WASHER                     | 4        | 4   |
| 27   | 223 10 224 | FLANGE, output             | 1        | —   |
| 27   | 223 15 224 | FLANGE, output             | —        | 1   |
| 28   | 252 10 222 | SCREW                      | 1        | 1   |
| 29   | 222 10 225 | FLANGE, output             | 2        | 2   |
| 30   | 223 10 301 | SHAFT, intermediate        | 1        | 1   |
| 31   | 223 10 302 | GEAR, intermediate         | 1        | —   |
| 31   | 224 15 302 | GEAR, intermediate         | —        | 1   |
| 32   | 223 10 304 | FRICTION WASHER            | 1        | 1   |


# GEAR-BOX



1



2



3



4



5



6



7



8



9



10



11



12



13




14



15



16



17




18




19




20



21



22



23




24



25



26



27



28



29



30



31



32



33



34



35



36



37



38



39



40



41



42



43



44



45



46



47



48



49



50



51



52



53



54



55



56




57



## GEAR-BOX

| Item | Part no.   | Description                  | Quantity |     |
|------|------------|------------------------------|----------|-----|
|      |            |                              | 2:1      | 3:1 |
| 33   | 222 10 206 | NEEDLE BEARING, intermediate | 1        | 1   |
| 34   | 223 10 401 | CONTROL, housing             | 1        | 1   |
| 35   | 223 10 402 | CONTROL, excentric           | 1        | 1   |
| 36   | 222 10 403 | ARM, control                 | 1        | 1   |
| 37   | 252 10 408 | O'RING, excentric            | 1        | 1   |
| 38   | 252 10 411 | SPRING, control              | 1        | 1   |
| 39   | 222 10 413 | CONTROL, level               | 1        | 1   |
| 40   | 221 10 416 | BALL                         | 1        | 1   |
| 41   | 223 10 417 | O'RING, housing              | 1        | 1   |
| 42   | 252 10 418 | PIN, excentric               | 1        | 1   |
| 43   | 252 10 419 | PIN                          | 1        | 1   |
| 44   | 511 02 258 | SCREW, 933 M9x25             | 2        | 2   |
| 45   | 521 03 157 | SCREW, 912 M6x20             | 2        | 2   |
| 46   | 521 20 006 | NUT, 934 M6                  | 2        | 2   |
| 47   | 511 23 012 | NUT, 985 M12                 | 3        | 3   |
| 48   | 521 01 258 | SCREW, 931 M8x25             | 11       | 11  |
| 49   | 521 01 259 | SCREW, 931 M8x30             | 2        | 2   |
| 50   | 521 01 260 | SCREW, 931 M8x35             | 5        | 5   |
| 51   | 531 02 358 | SCREW, 933 M12x25 12 K.      | 1        | 1   |
| 52   | 510 30 008 | WASHER, plain 0 8            | 20       | 20  |
| 53   | 560 00 116 | WASHER, plain (copper)       | 1        | 1   |

# GEAR-BOX





**SOLÉ, S.A.**

Crta. Martorell a Gelida, Km.2  
Apartado Correos 15  
C.P.: 08760 Martorell (Barcelona)

Tel.: +34 93 775 14 00

Fax: +34 93 775 30 13

Tel. Recambios: +34 93 775 44 05

Fax Recambios: +34 93 776 53 79

E-mail: [sole@solediesel.com](mailto:sole@solediesel.com)

Web: [www.solediesel.com](http://www.solediesel.com)